


































TERMINALS

Terminal shapes vary from one battery to another. By identifying the correct replacement battery from the listing in this book, you are assured of the proper terminal configuration. For custom applications, refer to the following chart to identify terminal shape and corresponding batteries.

Terminal Shape				Battery Type
Type	Front	Side	Top	
1				KIX30L-BS YB30L-B 12N18-3
2				YB7L-B2 YB9L-A2 YB9L-B2 YB16AL-A2 12N9-4B 12N9-3A 12N5.5-4A
3				YB7C-A YB14L-A1 YB16B-A1 Y60N24AL-B Y60N24-A Y60N24L-A 12N24-3 12N24-4 12N24-3A KTZ19S
4				YB10A-A2 YB10L-A2 YB10L-B2 YB12B-B2 YB12C-A YB14A-A1 YB14-A2 YB14A-A2 YB14L-A2 SYB14L-A2 YB14-B2 YB16B-A YB16CL-B YB16C-B Y50N18L-A3 12N10-3A-2 12N11-3A-1 12N14-3A 12N14-3B KTX14AH-BS KTX14AHL-BS YTX7A-BS YTX9-BS YTR9-BS YTX12-BS YTX14-BS YTX14L-BS YTX15L-BS YTX16-BS KTX16-BS KTX16L-BS KTX16CL-BS YTX20-BS YTX20L-BS YTX20H-BS YTX20HL-BS YTX20HL-BS-PW KTX24HL-BS
5				YT4L-BS YTX4L-BS YT5L-BS YTX5L-BS YTX7L-BS YB5L-B YB4L-A YB4L-B
6				YB3L-A YB3L-B YB6-A YB6L-B YB6.5L-B YB7A-A YB7-A YB7L-A YB7L-B YB7B-B YB9A-A YB9-B YB9L-B YB10L-B YB12A-A YB12AL-A YB12A-A YB16-B YB16-B-CX YB16L-B YB16HL-A-CX SYB16L-B 12N5-4B 12N5.5-3B 12N5.5A-3B 12N7-3B 12N7-4A 12N7-4B 12N7A-3A(YB7BL-A) 12N7B-4A 12N7D-3B 12N9-3A-1 12N9-3B 12N9-4B-1 12N10-3A 12N10-3B 12N10-3A-1 12N11-3B 12N12N-4A-1 6N11A-3 6N11A-4 6N11A-1B 6N11A-3B 6N11-2D 6N12A-2D 6N12A-2C B39-6 B38-6A B49-6 6YB8L-B
7				HYB16A-A YB18-A YB18L-A Y50N18A-A Y50N18L-A Y50N18L-A-CX SY50N18L-AT 12N18-3A YTX16-BS-1
8				H-12
9				51814 51913 53030 53211
10				KT7B-4 KT7B-BS KT9B-4 KT9B-BS KT12B-4 KT12B-BS KT12A-4 KT12A-BS KT14B-4 KT14B-BS KTZ5S KTZ7S KTZ9S KTZ10S KTZ10S-BS KTZ12S KTZ12S-BS KTZ14S KTZ14S-BS YTX20CH-BS
11				KTR4A-BS KT4B-5